


RESET

Shut off power and then restore



MOTOR FEEDBACK
THE MOTOR
IS NOT PROGRAMMED


NO MOTOR FEEDBACK
THE MOTOR
IS ALREADY PROGRAMMED

Carry out the
programming procedure



**Cancel
programming:**

- Shut off power for 5 sec
- Power on again



Press the three buttons
at the same time
Motor feedback



Press for 7 sec
until you achieve
2 Feedback

MODIFYING THE LIMIT SWITCHES


- Carry out the reset procedure
- Repeat programming

ADDING A CONTROL POINT

Programmed remote control



Remote control to be programmed



DELETING A CONTROL POINT

**Programmed remote control
(to be kept)**



**Programmed remote control
(to be eliminated)**



**Electronic wired radio motor with
3 limit switches for:**
rolling shutters with rigid links and
stoppers (not necessary when the motor is in
manual setting mode)




Limit switch automatic programming

Attention: the rolling shutter must be equipped with rigid links and stoppers

- 1 Press the up and down buttons simultaneously - Feedback



- 2 Check rotating direction



- 2a If the rotating direction is correct, wait 5 sec Feedback
End of programming

- 2b To reverse the rotating direction, keep pressed stop until Feedback is issued within 5 sec
End of programming



Attention: if you exceed 5 seconds when reversing the rotating direction, cut off power and restart from step 1.


Limit switch manual programming

Adhere to the procedure: start from the up limit switch

- 1 Press the up and down buttons simultaneously - Feedback



- 2 Check rotating direction



- 2a If the rotating direction is correct, wait 5 sec Feedback

- 2b To reverse the rotating direction, keep pressed stop until Feedback is issued within 5 sec



Attention: if you exceed 5 seconds when reversing the rotating direction, cut off power and restart from step 1.

- 3 Enter manual adjustment mode.
Keep pressing the up and down buttons at the same time, up to Feedback



- 4 Reach the up limit switch position



- 5 Record the up limit switch position and keep pressed, up to Feedback



Limit switch manual programming

Adhere to the procedure: start from the up limit switch

- 6 Reach the down limit switch position



- 7 Record the down limit switch position and keep pressed, up to Feedback



Limit switch up/down/programming end

- 8a Keep pressing the up and down buttons at the same time to end programming - 2 Feedback



Limit switch up/down/intermediate

- 8b To reach the intermediate limit switch position, press the up button until you reach the required position.



Confirm via the stop button to end programming - 2 Feedback



Limit switch up/down/slats opening

- 8c To reach the slats' opening limit switch position, press the down button until you reach the required position.



Confirm via the stop button to end programming - 2 Feedback

